following national standards are widely accepted. sources. However, the available from several Mailbox design and installation standards are

usps.com/manage/mailboxes.htm The United States Postal Service (USPS) Mailbox Guidelines.

with construction of privately owned mailboxes and is less focused on postal operations. store.transportation.org/ Chapter 11 (Erecting Mailboxes on Streets and Highways) deals Transportation Officials (AASHTO) Roadside Design Guide The American Association of State Highway and Item/PublicationDetail?ID=1807

the sidewalks must remain compliant with ADA requirements: In addition, if the mailbox is installed in an area with sidewalks,

and usable by individuals with disabilities. ada.gov/ to ensure sidewalks and other facilities are accessible regs2010/2010ADAStandards/2010ADAstandards.htm#c4 American Disabilities Act (ADA) has minimum requirements

mainedot.gov/winterdriving/mailboxpolicy/ **MaineDOT Mailbox Guidelines**



Mailbox Installation on Maine's State and State-Aid Highways

Mailbox installations are allowed within the right-of-way of Maine's state and state-aid highways. However, there are two very important conditions.


- 1. The mailbox must be installed in a way that:
- ensures the mail can be delivered; and
- doesn't create an obstacle or a safety hazard for those using or maintaining the highway.
- 2. The mailbox is installed entirely at the owner's risk. If the mailbox is damaged during any MaineDOT operation, including snowplowing, the property owner is not entitled to replacement or compensation. In fact, if the mailbox was not installed according to the standards outlined in the policy, the owner may be held liable for injuries or damages that may be incurred.

Mailbox Installation Standards

Here are some details regarding mailbox height, location, offset, and post type to reduce the chances for damage.

General Location:

Whenever possible, place your mailbox after your driveway opening. This location improves its visibility, minimizes the amount of snow that comes off the plow, and improves the approach for your mail carrier.



(hg. a)

10

Mailbox Support Design:


In many cases, it is best to use an extended arm post with a free-swinging suspended mailbox (fig. b). This allows snowplows to sweep near or under the box without damage, and provides easy access for your mail carrier. Place a red reflector on the arm at the point closest to the road. This will help your local snowfighter see and avoid your mailbox during winter storms.

Offsets from Roads:

Mailboxes should be set back from the edge of the shoulder, regardless of whether the shoulder is gravel or paved. In other words, the face of the mailbox should be at least one foot back from the edge of the normally plowed surface of the highway or the face of curb (fig. b). Greater offset distances are encouraged so the mail carrier can move out of traffic and to minimize potential damage to your mailbox.

A mailbox in a sidewalk should leave at least 36 inches behind the back of the box or the post, whichever is located the furthest from the road (fig. b).

Mailbox Support Design and Road Offsets



(fig. b)

Post Size, Type, and Embedment:

Mailbox posts must be sturdy enough to hold up the mailbox in all types of weather. However, they can't be so rugged that they present a hazard to vehicles that leave the road. If a mailbox support is struck by a vehicle, it must easily break away. Therefore, the following types of posts are recommended:


- 4" x 4" wooden posts embedded two feet into the ground (fig. c). Larger wooden posts (4" x 6" or 6" x 6") may be used only if the post is drilled through with an appropriate spade bit to create a shear plane (fig. d).
- One-inch to two-inch round diameter steel or aluminum pipe, or standard U-channel post embedded two feet into the ground (fig. e).

Unacceptable Mailbox Supports Include:

- anything filled with concrete,
- masonry and stone structures
- heavy steel structures, and
- most objects that were intended for other uses (e.g., antique plows, I-beams, etc.).

Mailboxes, attachments or support systems not consistent with this policy are considered **deadly fixed objects** and are in violation of Maine law (23 MRSA §1401-A). When MaineDOT sees this type of installation, the owner will be informed and immediate removal will be requested. If the property owner doesn't comply with this request, MaineDOT may remove the installation and seek reimbursement from the property owner for all costs.


Acceptable Mailbox Supports



Mailbox Height:

According to USPS standards, a mailbox must be installed so the bottom of the mailbox is between 41 inches and 45 inches above the highway shoulder. MaineDOT recommends the height be closer to the 45-inch measurement to minimize the chances of being struck by the plow truck wing (fig. f).

MaineDOT recommends a height of 45 inches above the highway shoulder.



(fig. f)

If you live on a state highway or a city street, here's how you can prevent a "second shove!"!

